

Propeller installation

Location of propellers and clearance.

The installation of propellers is performed in accordance with the requirements of propeller manufacturer which are stipulated in Operation and Installation manuals [2], [3].

Propellers are installed on the engine abaft the wing (Fig. 2.2.1., 2.2.2.).

Any aerodynamic controller (ailerons, flaps, rudder) and also any pilot does not cross with the cone created by the line going through the centre of propeller bush on the angle 5° (2.2.2.).